





# 301 - Shop Stool With Backrest Assembly Instructions









### Tools Needed:



### Includes:


- (1) Stool Seat • (1) Stool Frame • (1) Wood Back Rest • (2) Back Braces

<p><b>4 x</b> </p> <p>1/4" Hex Cap</p>	<p><b>4 x</b> </p> <p>1/4" Lock Washer</p>	<p><b>4 x</b> </p> <p>1/4" Hex Nut</p>
<p><b>4 x</b> </p> <p>1/4" x 3/4" Hex Head Machine Screw</p>	<p><b>4 x</b> </p> <p>#12- 3/4" Wood Screw</p>	<p><b>4 x</b> </p> <p>1/4" x 1" Carriage Bolt</p>

### Steps:


# 1

Lay seat on a hard surface with under side up.




# 2

Turn stool frame upside down and line up holes in frame with pilot holes in seat fasten with (4) #12 x 3/4" wood screws.




3

Turn Stool upright. Attach wood stool back to back braces by inserting (4) 1/4" x 1" Carriage Bolts through wood back and stool back brace, and fasten with (4) 1/4" Hex Caps. **HAND TIGHTEN ONLY.**





4

Attach Back Braces with Back Rest to Stool Frame using (4) 1/4" x 3/4" Hex Head Machine Screws, 1/4" Lock Washers, and 1/4" Hex Nuts. **HAND TIGHTEN ONLY.**



5

Square up Back Rest to Frame if needed. Tighten Carriage Bolts in wood Back Rest. The Bolt will indent (set itself) into the wood back.



After all brackets are in place, make sure stool is square and then, tighten all screws.